

Data PP

May 3, 2025

1 Importing Necessary Libraries

```
[5]: import os
import wfdb
import numpy as np
import seaborn as sns
import pandas as pd
import matplotlib.pyplot as plt
from sklearn.preprocessing import LabelEncoder
import tensorflow as tf
from tensorflow.keras.models import Sequential
from tensorflow.keras.layers import Conv1D, MaxPooling1D, Dense, Flatten, \
    Dropout, BatchNormalization
from sklearn.model_selection import train_test_split
```

2 Extracting the Patient IDs

```
[26]: # Patient IDs
pid = sorted(list({i.split(".")[0] for i in os.listdir("../mitdb/"))})
```

```
[28]: len(pid)
```

```
[28]: 48
```

```
[30]: pid
```

```
[30]: ['100',
      '101',
      '102',
      '103',
      '104',
      '105',
      '106',
      '107',
      '108',
      '109',
      '111',
```

```
'112',  
'113',  
'114',  
'115',  
'116',  
'117',  
'118',  
'119',  
'121',  
'122',  
'123',  
'124',  
'200',  
'201',  
'202',  
'203',  
'205',  
'207',  
'208',  
'209',  
'210',  
'212',  
'213',  
'214',  
'215',  
'217',  
'219',  
'220',  
'221',  
'222',  
'223',  
'228',  
'230',  
'231',  
'232',  
'233',  
'234']
```

3 Data Exploration and Processing

3.1 Annotation

```
[38]: df = pd.DataFrame()
```

```
[42]: ann = wfdb.rdann(f"../mitdb/{pid[0]}", "atr")
```

```
[ ]: ann.symbol
```

```
[44]: np.unique(ann.symbol, return_counts = True)
```

```
[44]: (array(['+', 'A', 'N', 'V'], dtype='<U1'),  
      array([ 1, 33, 2239, 1], dtype=int64))
```

```
[48]: for i in pid:  
      # Annotation Extraction  
      ann = wfdb.rdann(f"../mitdb/{i}", "atr")  
      sym = ann.symbol  
      values, counts = np.unique(sym, return_counts = True)  
  
      data = pd.DataFrame({"Patient ID": [i] * len(counts), "Symbol": values,  
↪ "Count": counts})  
  
      df = pd.concat([df, data], axis = 0)
```


```
[49]: df
```

```
[49]:
```

| | Patient ID | Symbol | Count |
|----|------------|--------|-------|
| 0 | 100 | + | 1 |
| 1 | 100 | A | 33 |
| 2 | 100 | N | 2239 |
| 3 | 100 | V | 1 |
| 0 | 101 | + | 1 |
| .. | ... | ... | ... |
| 0 | 234 | + | 3 |
| 1 | 234 | J | 50 |
| 2 | 234 | N | 2700 |
| 3 | 234 | V | 3 |
| 4 | 234 | ~ | 8 |

[283 rows x 3 columns]

```
[52]: sns.countplot(x = "Symbol", data = df, hue = "Symbol", palette = "PuBuGn",  
↪ legend = False)  
plt.ylabel("Count")  
plt.show()
```



```
[54]: # Obtained from external sources

# Non Beat Symbols
nonbeat = ['[', '!', ']', 'x', '(', ')', 'p', 't', 'u', '`', '␣',
           '\'', '^', '|', '~', '+', 's', 'T', '*', 'D', '=', '"', '@', 'Q', '?']

# Abnormal Beat Symbols
abnormal = ['L', 'R', 'V', '/', 'A', 'f', 'F', 'j', 'a', 'E', 'J', 'e', 'S']

# Normal Beat Symbols
normal = ['N']
```

```
[56]: df["Category"] = -1
df.loc[df.Symbol == "N", "Category"] = 0

for i in abnormal:
    df.loc[df.Symbol == i, "Category"] = 1
```

```
[58]: df
```

```
[58]: Patient ID Symbol Count Category
0      100      +      1      -1
1      100      A     33       1
2      100      N    2239       0
3      100      V      1       1
0      101      +      1      -1
..      ...      ...      ...      ...
0      234      +       3      -1
1      234      J     50       1
2      234      N    2700       0
3      234      V       3       1
4      234      ~       8      -1
```

[283 rows x 4 columns]

```
[60]: df.groupby("Category").Count.sum()
```

```
[60]: Category
-1      3186
0     75052
1     34409
Name: Count, dtype: int64
```

```
[62]: # Removing the non-beat data from the dataframe
df = df[df["Category"] != -1]
```

```
[64]: df.groupby("Category").Count.sum()
```

```
[64]: Category
0     75052
1     34409
Name: Count, dtype: int64
```

```
[66]: # Saving the DataFrame
df.to_csv("../Annotation.csv", index = False)
```

3.2 ECG

The `p_signal` contains the raw ECG signals as a 2D array.

The `r_peaks` (`ann.sample`) obtained from annotation contains the indexes where the heart beats (biggest deflection in the ECG graph) as 1D array

```
[73]: # Load ECG signal
rec = wfdb.rdrecord('../mitdb/100')
sig = rec.p_signal


# Load annotations
ann = wfdb.rdann('../mitdb/100', 'atr')
```

```
# Get the indices of R-peaks in the signal  
# Assuming that the heart beat is 75, then the heart beats around 2250 times  
r_peaks_indices = ann.sample
```

```
[75]: len(sig)
```

```
[75]: 650000
```

```
[79]: plt.plot(sig[270:520])  
plt.show()
```



```
[81]: sig[270:520].dtype
```

```
[81]: dtype('float64')
```

```
[83]: ann.sample.shape, len(ann.symbol)
```

```
[83]: ((2274,), 2274)
```

```
[85]: ann.sample[:5]
```

```
[85]: array([ 18,  77, 370, 662, 946], dtype=int64)
```

```
[87]: ann.symbol[:5]
```

```
[87]: ['+', 'N', 'N', 'N', 'N']
```


```
[89]: sig.shape, r_peaks_indices.shape
```

```
[89]: ((650000, 2), (2274,))
```

```
[91]: r_peaks_indices[:5]
```

```
[91]: array([ 18,  77, 370, 662, 946], dtype=int64)
```

```
[93]: plt.plot(sig[:150])  
plt.title("Sample ECG")  
plt.show()
```



```
[95]: X = [] # Features  
y = [] # Labels
```

```
[99]: for id in pid:
      rec = wfdb.rdrecord(f"../mitdb/{id}")
      signal = rec.p_signal

      ann = wfdb.rdann(f"../mitdb/{id}", "atr")
      r_peaks_indices = ann.sample

      symbols = ann.symbol

      for idx, r_peak in enumerate(r_peaks_indices):
          start = r_peak - 100
          end = r_peak + 150

          if start >= 0 and end < len(signal):
              X.append(signal[start:end, :].astype(np.float16))
              y.append(symbols[idx])
```

```
[ ]: X = np.array(X)
```

```
[ ]: y = np.array(y)
```

```
[15]: X.dtype
```

```
[15]: dtype('float16')
```

```
[18]: encoder = LabelEncoder()

      y = encoder.fit_transform(y).astype(np.int8)
```

```
[20]: y.dtype
```

```
[20]: dtype('int8')
```

```
[22]: X.shape, y.shape
```

```
[22]: ((112559, 250, 2), (112559,))
```

```
[24]: mapping_file = '../Encoded Classes.txt'
      label_encoder_mapping = {}
      with open(mapping_file, 'r', encoding='utf-8') as file:
          for line in file:
              if '→' in line:
                  symbol, code = line.strip().split('→')
                  symbol = symbol.strip()
                  code = int(code.strip())
                  label_encoder_mapping[symbol] = code
```



```

nonbeat_symbols = ['[', '!', ']', 'x', '(', ')', 'p', 't', 'u', '^', '\', '^',
↳ '|', '~', '+', 's', 'T', '*', 'D', '=', '"', '@', 'Q', '?']

nonbeat_encoded = [label_encoder_mapping[symbol] for symbol in nonbeat_symbols
↳ if symbol in label_encoder_mapping]
print(f"Non-beat encoded labels: {nonbeat_encoded}")

mask = np.isin(y, nonbeat_encoded, invert=True)

X_cleaned = X[mask]
y_cleaned = y[mask]
print(f"Shape after cleaning: X_cleaned = {X_cleaned.shape}, y_cleaned =
↳ {y_cleaned.shape}")

```

Non-beat encoded labels: [14, 0, 15, 20, 21, 22, 2, 1, 10]

Shape after cleaning: X_cleaned = (109416, 250, 2), y_cleaned = (109416,)

```

[ ]: unique_classes = np.unique(y_cleaned)
class_counts = np.array([np.sum(y_cleaned == c) for c in unique_classes])
print("Remaining classes and their counts:")
for c, count in zip(unique_classes, class_counts):
    print(f"Class {c}: {count} samples")

max_class_id = np.max(unique_classes)
print(f"New output layer size needed: {max_class_id + 1}")

label_encoder = LabelEncoder()
y_cleaned = label_encoder.fit_transform(y_cleaned)

reverse_mapping = {v: k for k, v in label_encoder_mapping.items()}

symbol_to_new_id = {reverse_mapping[old_id]: new_id
    for old_id, new_id in zip(label_encoder.classes_,
↳ label_encoder.transform(label_encoder.classes_))
    if old_id in reverse_mapping}

with open('../Remapped_Symbol_Classes.txt', 'w', encoding='utf-8') as f:
    for symbol, new_id in symbol_to_new_id.items():
        f.write(f"{symbol} → {new_id}\n")

print("Symbol-to-new-ID mapping saved to 'Remapped_Symbol_Classes.txt'.")

```

```

[78]: np.save("Features.npy", X_cleaned)
np.save("Labels.npy", y_cleaned)

```